

Kayak Ladder Lift & Launch

Kayak Roller Accessory



Attach the roller accessory onto the launch platform during Step 13 of the Kayak Ladder Lift & Launch assembly instructions.

Step 13: Attach bunk support rails:

- 13A.** Take (1) of the bunk support rails and insert it into the slots in the launch platform.
- 13B.** Align the two holes on the bunk support rail with the holes in the launch platform.

Before securing the bunk support rail, place the roller assembly on the right side (as you look out towards the water) of the launch platform.

- 13C.** Secure with 3 ½" hex bolt, washer and lock nut.
- 13D.** Repeat with the other bunk support rail.



Before securing the bunk support rail, place the roller assembly on the right side (as you look out towards the water) of the launch platform. Thread the 3 ½" hex bolt with washer through the roller assembly and launch frame (with bunk support inserted). Secure with lock nut.

